

English Language V1.50

ROBONOVA-I



Index

-Table of Contents-**I. Introduction**

1. Easy to Build - 3
2. Servo Motors
3. Control Boards, MR-C3024
4. Metal Framework
5. Battery and Charger
6. The Key - "Easy To Operate"
7. Requirements and Specification - 4

II. Before You Begin - 8**III. Assembly Notes**

1. ROBONOVA-I Kit Parts List - 10
2. Notes on the HSR-8498HB Servos - 12
3. Notes on Kit Assembly - 14

IV. Assembly

1. Servo Placement - 17
2. Leg Assembly - 18
3. Arm Assembly - 31
4. Body Assembly - 34
5. Attaching the Legs and Arms to the Body - 39
6. Attaching the Head to the Body - 41
7. Attaching the Front Body Cover - 42
8. Attaching the Controller to the Robot - 43
9. Cable Arrangement - 45
10. LED and IR Connection - 53
11. Final Assembly - 58
12. Charging - 61

V. Quick Start

1. About RoboBASIC - 62
2. Installing the Software - 62
3. Upload the Template Program - 64
4. Zero Settings - 66
5. Operating the ROBONOVA-I - 70

VI. Software Overview

1. Operational Overview of RoboBASIC - 67
2. RoboSCRIPT - 78
3. RoboREMOCON - 82

VII. Programming the ROBONOVA-I

1. Template Program - 84
2. Adding Routines and Sensors - 90

VIII. HMI Protocol - 93**IX. Troubleshooting - 94****X. HMI Robot Servo General Information - 95****I. Introduction****1. Easy to Build**

Your ROBONOVA-1 kit was designed for easy assembly in 6 to 8 hour using only a screwdriver.

2. Servo Motors**Completely Designed Servo Only for Robot Operation**

This fully articulating, 12" high, mechanical man is controlled with 16 powerful HSR-8498HB digital servos built specifically for the ROBONOVA-1 by Hitec. These custom servos feature "set pin" locking of the servo arms for easy assembly, over-voltage current protection, super strong Karbonite gear trains and "position feedback" technology for simple programming

3. Control Boards, MR-C3024**Micom Board with Flexible Interface**

The control board is the heart of the ROBONOVA-1. Secured to the back of the robot under a strong plastic case, the control board can operate up to 24 servos and 16 accessory modules. Optional devices will eventually include gyro's, acceleration sensors, speech synthesis modules and operational devices such as Bluetooth controllers and R/C transmitters and receivers. This flexible and sophisticated interface allows the user to customize ROBONOVA-1 into the robot of their dreams. Firmware can be automatically upgraded when connected to a PC.

4. Metal Framework

The custom gold anodized metal servo brackets serve as a strong and lightweight exoskeleton. ROBONOVA-1 also features durable plastic body case components that protect the control board and battery from damage.

5. Battery and Charger

Powering the ROBONOVA-1 is a 5 cell, environmentally friendly NiMH rechargeable battery that delivers around 1 hour of operational time. The included D/C to D/C charger features a protection circuit to help prevent battery charging mishaps.

6. The Key - "Easy To Operate"

ROBONOVA-1, Robot Programming Made Easy. Users of this exciting robot package have an opportunity to learn robot technology first hand. Programming is simple with the supplied RoboScript and RoboBasic software via the included PC interface cable.

A. RoboScript & RoboRemocon

Beginners to robot programming technology will be pleased to use the supplied RoboScript programming software. Without knowing any programming language at all, users can create operational subroutines with the "click of a mouse". Use the RoboRemocon software to control your ROBONOVA-1 with the operational data created with RoboScript

B. RoboBasic

RoboBasic is a programming tool based on the BASIC programming language and is provided for the more advanced users. Containing specific commands for simple robot operation, RoboBasic can also be used in conjunction with RoboScript to increase the performance of the supplied Micom controller board.

C. HMI (Hitec Multi-protocol Interface)

- Upgrade firmware & various settings
- Parameters setting (2 types of Gains, Dead band etc.) and set value change during operation
- Compatible with PWM (Pulse Width Modulation) used in current radio control
- Control a maximum of 128 servo motors by daisy chaining them with a serial interface and PC
- Able to provide position feedback using the HMI

D. Catch & Play Function**Easy Programming Technique**

The simplest way to program ROBONOVA-1 is with the "catch and play" function. Using RoboScript or RoboBasic, just move the robot into any position and click the mouse to "capture" that position. Move the robot into another position and repeat the process. The software then links these "captured" positions and once activated, smoothly transitions the robots movements through these programmed positions.

7. Requirements and Specification

A. System Requirements:

- ☐ Windows * based PC
- ☐ 300MHz processor or higher
- ☐ 60MB of hard disk space
- ☐ 128MB of RAM
- ☐ Open COM port
- ☐ CD-ROM Drive 2x or greater

* Windows is the registered trademark of the Microsoft Corporation.



B. HSR-8498 Specifications:

- ☐ Interface: HMI protocol, PWM
- ☐ Operating voltage: 4.8V to 6.0Vdc
- ☐ Speed: 0.20sec/ 60° at 6.0V
- ☐ Stall Torque: 10kg/cm (139oz/in) at 6.0V
- ☐ Operating angle: 180°
- ☐ Weight: 55g (1.94oz)
- ☐ Dimension: 40 x 20 x 47mm (1.57 x 0.78 x 1.85in)
- ☐ Pulse specification:
- ☐ Neutral: 1500μs
- ☐ End to End travel (0 ~ 180°): 1100 ~ 1900μs
- ☐ Pulse duty cycle (refresh): 12 ~ 26ms (common = 21ms)



C. MR-C3024 Robot Controller Specifications

- ☐ CPU: Atmel ATMEGA128 8bit RISC
- ☐ I/O Ports: 24
- ☐ Servo Control: 24
- ☐ PWM DC Motor Control: 3
- ☐ A/D Conversion Channel: 8 ch
- ☐ Program Memory: 32Kbytes
- ☐ Ultrasonic Sensor: 12 ch
- ☐ IR Remote Control Reception: Yes
- ☐ RF Control Reception: Yes
- ☐ Common Features: 1. LCD Module Control
- ☐ ☐ 2. 6 Octave Piezo (Music, Voice)
- ☐ ☐ 3. RS-232 (UART) Serial Communication
- ☐ Misc: ☐ 1. Direct Serial Control (Using VB, VC++)
- ☐ ☐ 2. Robot Programming : Requires ROBOBASIC v2.0 or above
- ☐ ☐ 3. Download : Requires serial cable



MR-C3024 Layout


MR-C3024 pin configuration

S C L	S D A	P W M 2	P W M 1	P W M 0	L C D	T X	R X	Interface Cable connector	A D C 0	A D C 1	A D C 2	A D C 3	A D C 4	A D C 5	A D C 6	ADC7 / REMOCON
S11			ATMEGA 128												S12	
S10															S13	
S9															S14	
S8															S15	
S7													PIEZO		S16	
S6															S17	
S5															S18	
S4			S19													
S3			XTAL 7.3728Mhz							S20						
S2			BATTERY CONNECTOR							S21						
S1										S22						
S0										S23						

Pinout Description

- Servo motor connection ports (S0-S23) : 24 servo motor signal terminals
- Analog to digital signal conversion ports (AD0-AD7) : 8 AD conversion terminals
- High speed independent PWM ports (PWM0-PWM2) : 3 PWM terminals
- High speed serial communication terminals (RX, TX)
- IR remote control reception terminal (REMOCON-AD7)
- Serial LCD module connection terminal (LCD)
- Piezo connection terminal (PIEZO)
- Serial communication (I2C) terminal (SCL, SDA) : External expansion module terminal
- Power terminal (VCC, GND) : DC 4.5-6.0V power input terminal

ATMEGA128 pin configuration



Pin allocation chart

Pin I/O Port	ATMega 128 External Function	MR-C3024 Function
1. PEN	PEN ↔ AVCC	NC
2. PE0	RXD0 / PDI	RX
3. PE1	TXD0 / PDO	TX
4. PE2	XCK0 / AIN0	LCD
5. PE3	OC3A / AIN1	PWM 0
6. PE4	OC3B / INT4	PWM 1
7. PE5	OC3C / INT5	PWM 2
8. PE6	T3 / INT6	NC
9. PE7	ICP3/INT7	NC
10. PB0	/SS	S8
11. PB1	SCK	S9
12. PB2	MOSI	S10
13. PB3	MISO	S11
14. PB4	OC0	S12
15. PB5	OC1A	S13
16. PB6	OC1B	S14
17. PB7	OC2/OC1C	S15
18. PG3	TOSC2	LED0
19. PG4	TOSC1	LED1
20. RESET	RESET	RESET
21. VCC	VCC	VCC
22. GND	GND	GND
23. XTAL2	XTAL2	XTAL2
24. XTAL1	XTAL1	XTAL1
25. PD0	SCL / INT0	SCL
26. PD1	SDA / INT1	SDA
27. PD2	RXD1 / INT2	RXD
28. PD3	TXD1 / INT3	TXD
29. PD4	ICP1	NC
30. PD5	XCK1	BUZZER
31. PD6	T1	NC
32. PD7	T2	NC
33. PG0	/WR	NC
34. PG1	/RD	NC
35. PC0	A8	S23
36. PC1	A9	S22
37. PC2	A10	S21
38. PC3	A11	S20
39. PC4	A12	S19
40. PC5	A13	S18
41. PC6	A14	S17
42. PC7	A15	S16
43. PG2	ALE	NOT
44. PA7	AD7	S7
45. PA6	AD6	S6
46. PA5	AD5	S5
47. PA4	AD4	S4
48. PA3	AD3	S3
49. PA2	AD2	S2
50. PA1	AD1	S1
51. PA0	AD0	S0
52. VCC	VCC	VCC
53. GND	GND	GND
54. PF7	ADC7 / TDI	ADC 7
55. PF6	ADC6 / TDO	ADC 6
56. PF5	ADC5 / TMS	ADC 5
57. PF4	ADC4 / TCK	ADC 4
58. PF3	ADC3	ADC 3
59. PF2	ADC2	ADC 2
60. PF1	ADC1	ADC 1
61. PF0	ADC0	ADC 0
62. AREF	VCC	VCC
63. GND	GND	GND
64. AVCC	AVCC is the supply voltage pin for Port F and	




*Note: NC = No Control

II. Before You Begin

- This manual contains an explanation of the ROBONOVA-I hardware and its assembly, the MR-C3024 robot controller and the software used to program the robot.
- Please read this manual carefully and be aware of the products functions and usage. This manual is also provided in the PDF file format on the CD so a copy can be saved to hard disk or printed, whichever is required.
- The specifications may be changed without notice to improve the performance of the product or for other reasons. Check the Hitec homepage for the latest updates. (<http://www.hitecrobotics.com>)

1. Safety Precautions

Precautions are divided into three categories, Danger, Warning and Caution, according to their bearing on safety. Read the precaution notes thoroughly before attempting to assemble the kit.

-  **Danger:** Applied when the risk of Death, severe injury, or the possibility of property damage may occur if the instructions are not followed
-  **Warning:** Applied when either user injury or equipment damage may occur when the instructions are not followed.
-  **Caution:** Applied when there is the possibility of injury or equipment damage.

A. Assembly Precautions

This manual contains information on safety to prevent bodily injury or property damage.



Danger

- Pay attention to proper safety while the robot is operating.
- Performance and operation is not guaranteed since this is an unassembled kit and if assembled incorrectly injury or damage may occur.
- Assemble the kit in an area with adequate ventilation.



Warning

- Keep away from children. Though the product appears to be a toy, it may hurt a small child if left attended.
- Shut down and unplug the battery immediately if a problem occurs. If the product is broken, or exposed to liquid, flame, or heat, shock may occur.
- Never disassemble or modify the battery charger and cables.
(Cable repair is supported by customer service.)
- Unplug the battery charger when not in use.
- Never disassemble or modify the servo circuit boards.
- Do not use in hot, wet or cold conditions. This kit consists of precision components. If exposed to extreme conditions, failure may occur.
- Pay close attention to the construction of the robot. Since this is an unassembled kit, safety and performance is not guaranteed. If assembled incorrectly, damage or injury may occur.
- Always make sure the battery charge plug is secure when charging. Remove immediately when the charge process is complete.
- Please read the manual carefully. Note the direction of the servos and brackets when assembling. If assembled improperly, disassemble and reassemble correctly.



Caution

- The servos included in the kit require periodic maintenance to maintain optimum performance.
- Best performance is achieved when using the robot on a large, smooth, flat surface. If the surface is irregular or too small, the robot may fall and damage may occur.
- Do not hold the robot when turning it on or during operation.

B. Battery Management Safety

This kit contains a NiMH battery for the power source. The NiMH battery is a high power rechargeable battery and requires careful handling and storage.



Danger

- Never turn the robot on while the charger is connected. Doing so will result in damage to the controller board and/or servos.



Warning

Battery management

- The battery included in this kit has a minimal charge. A NiMH battery must be stored with some remaining battery power. If the NiMH battery is fully discharged and left for a longtime, the battery's performance will decrease.
- The battery must be disconnected from the controller board or the battery charger when not in use.
- Store the battery in a cool, dry place.

Charging time

- The battery will fully charge in approximately 70 minutes. This time will vary depending on remaining battery power.
- Never leave the battery unattended while charging.
- Stop the charge process if the battery becomes abnormally hot.
- Overcharging may result in damage to the pack.



Caution

Battery handling

- Do not disassemble or modify the battery connector and wiring.
- Make sure that foreign objects do not get into the connector pins and that no bare wires are exposed.
- Do not subject the battery to extreme temperatures or a humid environment. Store the battery in a cool, dry place.
- Keep away from other conducting sources during transport or storage.
- If the battery wires become worn or frayed, replace the battery pack.

First aid and disposal


- In the event that the battery is damaged and vents causing the electrolyte to encounter an area of skin or the eyes, rinse the affected area with water.
- In the case of contact with the eyes, consult a physician as soon as convenient.
- The batteries electrolyte is a toxic substance. It is not only harmful to the human body but may also damage home and furnishings.
- If the NiMH batteries no longer hold a charge, dispose of them properly in the trash or according to your countries rules and regulations.
- Do not dispose of them in an incinerator.

C. Tools Required for Assembly

- 1) High Quality Phillips screwdrivers (PH1 and PH2)
- 2) Tweezers
- 3) Wire cutters
- 4) Thread screw lock

































During the assembly process this icon will be used when thread screw lock is required.





III. Assembly Notes

1. ROBONOVA-I KIT Parts List

























						
6 PCS	4 PCS	8 PCS	2 PCS	1 PCS	1 PCS	1 PCS
HR1B-0001	HR1B-0002	HR1B-0003	HR1B-0004	HR1B-0005	HR1B-0006	HR1B-0007
Tapped U Type Universal Bracket	Non-Tapped U Type Universal Bracket	I-Type Universal Bracket	H-Type Bracket	Back Body Frame	Front Body Frame	Top Body Frame
						
1 PCS	1 PCS	1 PCS	1 PCS	1 PCS	2 PCS	2 PCS
HR1C-0001	HR1C-0002	HR1C-0003	HR1C-0004	HR1C-0005	HR1C-0006 (Top Hand)	HR1C-0007 (Bottom Hand)
Front Body Cover	Back Body Cover	Goggle Cover	Front Head Cover	Back Head Cover	Top Hand Cover	Bottom Hand Cover
						
1 PCS	3 PCS	1 PCS	3 PCS	1PCS	1 PCS	1 PCS
HSR-8498HB1R200 (Sticker No.1)	HSR-8498HB1R300 (Sticker No.2)	HSR-8498HB1L200 (Sticker No.3)	HSR-8498HB1L300 (Sticker No.4)	HSR-8498HB2R200 (Sticker No.5)	HSR-8498HB2R400 (Sticker No.6)	HSR-8498HB2L200 (Sticker No.7)
						
130 PCS	28 PCS	6 PCS	2 PCS	40 PCS	12 PCS	4 PCS
PH/T-2 2 x 4 NI	PH/T-2 2 x 5 NI	PH/T-2 2 x 8 NI	PH/T-2 2 x 26 BK	PH/M 2 x 4 NI	PH/M 2.6 x 4 NI	PH/M 3 x 4 NI
Pan Head Tapping Screw	Pan Head Tapping Screw	Pan Head Tapping Screw	Pan Head Tapping Screw	Pan Head Screw	Pan Head Screw	Pan Head Screw

	
1 pc	1 pcs
Pin Cover	Battery Wire Protector
For MR-C3024	



Remocon and IR sensor
Optional (not in all kits)



Horns already installed on servos.

					
1 PCS	2 PCS	2 PCS	2 PCS	2 PCS	1 EA
HR1B-0008	HR1B-0009	HR1B-0010	HR1B-0011	HR1B-0012	MR-C3024
Bottom Body Frame	Shoulder Back Universal Bracket	Shoulder Front Universal Bracket	Hand Bracket	Foot Bracket	Controller
					
1 PCS	1 PCS	1 PACK	1 EA	1 EA	1 EA
HR1C-0008	HR1C-0009	Ni-Mh Battery (1,000mAh/ 6.0V/ 5 Cell)	CD-ROM	Interface Cable	Wall Charger
Right Foot Cover	Left Foot Cover	6.0 V 5Cell	ROBOBASIC & ROBONOVA-I User Manual	MR-C3024 Serial Interface Cable	6V/ 1,000mAh / 100-240V
					
1 PCS	1 PCS	1 PCS	1 PCS	1 PCS	2 PCS
HSR-8498HB2L400 (Sticker No.8)	HSR-8498HB3R200 (Sticker No.9)	HSR-8498HB3L200 (Sticker No.10)	HSR-8498HB2R300 (Sticker No.11)	HSR-8498HB2L300 (Sticker No.12)	Insert Bolt 3/4
					Insert Bolt
					
4 PCS	28 PCS	1 PCS	8 PCS	28 PCS	2 PCS
Support 3 x 5mm	FW 7.6 x 2.8 x 0.5 NI	HSR8498HA2	Cable Tie	Cable Clamp	Lug
Support	Flat Washer	Wheel Horn			

**Additional screws and washers can be found at local surplus retailers.




PH/M (Machined Screw)

PH/T (Tapping Screw)

2. Notes on the HSR-8498HB Servos

The HSR-8498 servos within the kit are assembled in a variety of configurations. Each configuration is optimized for a specific joint in the robot.

The servo cables exiting the servos are composed of three colored wires. Two are black and one is gray. At no time is it required to disassemble the cable nor is it suggested.




The following pictures give a visual example of the different servo configurations and wire lengths. The HSR-8498HB servos are provided in the following configurations:

There are three different case types.



Three different cable lengths.



Two different cable orientations.



Left orientation has the "CE" mark.


Right orientation does not have the "CE" mark.



3. Notes on Kit Assembly



A. Servo Horns

Included in the kit are four different types of horns. These are already attached to the servos. The following is for informational purposes.





The four horns are divided into two different groups. Two are given the name Splined horns and two Idler horns. Review the pictures to differentiate between the two groups.

The splined horns have numbers embossed toward the center of the horn. These horns are also keyed to improve assembly accuracy.



This picture shows the servo with the splined horn removed. The screw used to attach the horn is a BH/T 2.6 x 6mm.

The idler horns are not keyed nor do they have numbers embossed on them. These horns are designed to spin freely when attached to the servos.




This picture shows the servo with the idler horn removed. The horn is attached to the servo with a BH/T 2.6 x 6mm screw and a 2.8 x 7.6mm washer.


B. Attaching Brackets to the Servos

There are a different ways to attach brackets to the servos. Some brackets attach to the servo case and others attach to the horns.


On some of the HSR-8498HB servos the case has pentagonal sections.




To attach a bracket to these sections, it is necessary to remove the three screws, place the bracket over the section, and reinstall the screws.



To attach a bracket to the horns it may be necessary to bend the bracket slightly.




Once the screws are inserted, the bracket will move back into shape.



IV. Assembly

1. Servo Placement




Each servo has been given a number that corresponds to its case, wire length and direction. This picture shows the servo numbers and placement within the robot. View is from the back.



2. Leg Assembly


A. Ankle and Thigh Bracket Assembly

Parts Required:

		
HR1B-0001	HR1B-0002	PH/M 2 x 4mm
4 pcs	4 pcs	16 pcs

Within the kit there are two different U-shaped brackets. There are four HR1B-0002 and six HR1B-0001. To distinguish between the two types refer to the following pictures and text.


The first difference is that the six brackets on the right have twelve tapped holes each. The four brackets on the left do not.



The second difference is the HR1B-0001 has a wider flange than the HR1B-0002.






To assemble the ankle and thighs, use one HR1B-0001 and one 0002 bracket and attach them together with four PH/M 2 x 4mm screws.




Using the picture as a guide, place the two brackets together and insert the screws.

B. Right and Left Foot Assembly



Parts required:

(Sticker No. 6)	(Sticker No. 8)	
		
HSR-8498HB2R400	HSR-8498HB2L400	HR1B-0012
1 pc	1 pc	2 pcs

Layout the parts to be used as shown in the picture. Remove both the spline and idler horns from the servos. Remove the two black screws from the lower half of the servos on the splined horn side and the two silver screws from the lower half on the idler horns side.




Starting with the right foot, place the No. 8 servo into the a foot bracket and reinstall the removed screws. Make special note of the black and silver screw locations and that they are inserted into the correct side of the servos. They are not interchangeable.



Use the same method to assemble the left foot.

Completed foot assemblies.





C. Attaching the Right and Left Ankle Assembly

Parts required:

		
Assembled foot	Ankle bracket	PH/T-2 2 x 4mm
2 sets	2 sets	14 pcs


Begin with the right foot. Place the ankle bracket over the foot servo horns. It might be necessary to bend the bracket to fit over the horns. When the screws are tightened the bracket will bend back into shape.



Before inserting the screws, make sure that the HR1B-0001 bracket of the ankle is facing down toward the servo.

Position the ankle over the right foot so the number 7 on the splined horn is at 12 o'clock in relation to the ankle. Install four PH/T 2 x 4mm screws into the splined and three into idler horns. At this time do not install a screw in the 6 o'clock position of the idler horn. The completed right foot will appear as the picture.

Note on the "O'Clock" terminology: This term relates to the numbers on a clock. 12 o'clock is at the top and 6 o'clock is at the bottom. This term will be used throughout the manual.










The left foot and ankle are attached in a similar fashion as the right foot. When positioning the ankle over the foot, the number 3 on the splined horn will be at the 12 o'clock position. Install the screws into the splined and idler horns. Again do not install a screw at the 6 o'clock position of the idler horn.



D. Cable Arrangement and Foot Covers



Parts required:

				
Foot assemblies	HR1C-0008	HR1C-0009	PH/M 2 x 4mm	FW 6 x 2.2 x 0.5mm
2 sets	1 pc	1 pc	8 pcs	2 pcs
				
Cable clamp	PH/T-2 2 x 4mm			
2 pcs	2 pcs			

Arrange the cable for the right foot so it is in the same position as the one in the picture.




Bend the cable clamp around the cable.





Slide the washer onto a PH/T-2 2x4mm screw. Insert the screw into the holes of the cable clamp and install in the 6 o'clock position of the idler horn.

Assemble the left foot in the same manner.



The completed feet will match those in the picture.


Slide a HR1C-0008 foot cover over the right foot. The correct orientation is for the flat side of the cover to face toward the inside of the foot and the beveled side to face the outside. Use the picture as a reference.



Double check the servo cable to make sure it is not crimped or caught up in the cover.

Insert four PH/M 2 x 4mm screws into the cover and secure it to the foot.




Assemble the left foot in the same manner.




When complete the feet will match the picture.

E. Shin Assembly


Parts Required:

No. 2	No. 4	
		
HSR-8498HB1R300	HSR-8498HB1L300	HR1B-0002
1 pc	1 pc	4 pcs

Begin by taking a close look at the HR1B-0003 brackets. One edge of the bracket is smooth and the other is sharp. For safety purposes, the smooth edge should face toward the outside of the servo.




Remove the screws from the pentagonal portion of the servos. Note their placement during this process. For reference, the splined side of the servo has two black screws and one silver screw. The idler side has three silver screws.




Lay one bracket against the servo as shown in the picture and reinsert the screws. Read the note below before finishing. Do this until each servo has one bracket on the splined side and one on the idler side. Again take care to place the soft edge of the bracket so it is facing out.

Note:

At this time do not reinstall one of the long silver screws on the idler horn side of each shin. The position of each screw has been circled in the picture. Set the screws aside for use at later time.








When complete, the shins will match the picture.




F. Knee Assembly

Parts required:

No. 1	No. 2	No. 3	No. 4	
				
HSR-8498HB1R200	HSR-8498HB1R300	HSR-8498HB1L200	HSR-8498HB1L300	HR1B-0004
1 pc	1 pc	1 pc	1 pc	2 pcs

To simplify construction, lay out the parts so they match the picture.




Remove the screws from the pentagonal portion of all the servos. Note their placement during this process. For reference, the splined side of the servo has two black screw and one silver screws. The idler side has three silver screws.



Starting with the right upper knee, place the bracket over the pentagonal section of servo No. 3. Use the picture as reference. Install the previously removed screws. Read the note below before finishing. Assemble the left upper knee in the same manner using servo No. 1.



Note: At this time do not reinstall the short silver screws on the idler side of each upper knee. The position of each screw has been circled in the picture. Set the screws aside for use at later time.



Again, starting with the right knee, place the bracket over servo No. 2. Note the orientation of the bracket to the servo in the picture.

Reinstall the previously removed screws. Read the note below before finishing. Assemble the left knee in the same manner using servo No. 4

Note: At this time do not reinstall one of the long silver screws on the idler side of each lower knee. The position of each screw has been circled in the picture. Set the screws aside for use at later time.




Double check the completed assembly against the picture to insure the cable direction matches.

G. Assembling the Whole Leg


Parts required:

Foot assembly	Shin assembly	Knee assembly	Thigh assembly	PH/T-2 2 x 4mm
2 sets	2 sets	2 sets	2 sets	21 pcs

For this step, gather the previously assembled components and lay them out so they match the picture.



Use this picture as a reference for general assembly and the splined horn alignment of the right leg. Do not install screws at the marked locations in the Idler Horn view.




Step 1.

Attach the ankle to the shin:

Attach the lower shin servo to the upper ankle bracket. The number 6 on the splined horn is at 12 o'clock. Insert four screws in the splined horn and three into the idler horn.

Do not install a screw at the 9 o'clock position of the idler horn.



Step 2.

Attach the shin to the lower knee:

Attach the lower knee servo to the upper shin bracket. The number 4 on the splined horn is at 12 o'clock. Insert four screws in the splined horn and three in the idler horn.



Do not install a screw at the three o'clock position of the idler horn.

Step 3.

Attach the upper knee to the thigh bracket:

Slide the thigh bracket over the upper knee servo. Use the picture to align the thigh bracket with the splined horn. Make sure that the number 8 on the splined horn is at 12 o'clock and mated to the HR1B-0002 bracket of the thigh (thin flange). Insert four screws in the splined horn and three into the idler horn.

Do not install a screw at the 3 o'clock position of the idler horn.




If the leg has been assembled correctly, each servo will have full range of motion. To test this, collapse the leg fully by hand.


If the leg does not collapse, double-check the splined horn alignment. If misaligned, remove the screws from the horns and reposition the brackets.

Use this picture as a reference for the splined horn alignment of the left leg. To assemble the left leg, attach the components in the same order as the right.

Do not install screws at the 3 o'clock position of the shin, the 9 o'clock position of the lower knee and the 9 o'clock position of the upper knee idler horns.






When complete, the legs will match those in the picture.



3. Arm Assembly


A. Bicep Assembly

Parts required:


No. 2	No. 4	
		
HSR-8498HB1R300	HSR-8498HB1L300	HR1B-0002
1 pc	1 pc	4 pcs

The shoulders are assembled in the same manner as the shins. Remove the screws from the pentagonal sections of the servo cases and attach the brackets by reinstalling the screws. Do not reinstall one of the long silver screws in each idler side of the bracket.

The locations are marked in the picture.









When complete the two biceps will match the picture.





B. Forearm and Hand Assembly

Parts required:

No. 11	No. 12			
				
HSR-8498HB2R300	HSR-8498HB2L300	HR1C-0006	HR1C-0007	HR1B-0011
1 pc	1 pc	2 pcs	2 pcs	2 pcs
				
PH/T-2 2 x 5mm				
8 pcs				

Remove the screws that are furthest away from the splined and idler horns. Remove the two black screws on the splined horn side and the two silver screws on the idler horns side. Attach the brackets as shown in picture.



Reinstall all the screws except for one silver screw in each forearm. Set this screw aside for use at a later time. Pay particular attention that the black and silver screws are inserted into the correct side of the servos, as they are not interchangeable.



Snap the two halves of the each hand together and secure to each forearm bracket with four PH/T 2 x 5mm screws each.




When complete the forearms will match the picture.

C. Completing the Arm Assembly

Parts required:



		
Bicep Assembly	Forearm Assembly	PH/T-2 2 x 4mm
2 sets	2 sets	14 pcs


Line up the components that make up the arm as shown in the picture.



Using the picture as a guide, connect the forearm to the shoulder with four screws in the splined horns and 3 in the idler horns. For both forearms, the number 1 on the splined horn should be a 12 o'clock.

Do not insert screws at the 3 o'clock position on the idler horn side of servo No. 12 and the 9 o'clock position of servo No. 11.





When complete the arms will match the picture.


4. Body Assembly

A. Shoulder Assembly


Parts required:

No. 9	No. 10		
HSR-8498HB3R200	HSR-8498HB3L200	HR1B-0009	HR1B-0010
1 pc	1 pc	2 pc	2 pc


Remove the four silver screws from the hornless side of each servo and the two black screws furthest away from the splined horn on the splined horn side.



Use this picture as an example of proper bracket placement.



Using the removed black screws, attach the HR1B-0010 bracket to the splined horn side of the each servo. Attach the HR1B-0009 bracket with the previously removed silver screws to the hornless side of each servo. Assemble both shoulders in the same manner. Use the picture as reference.




B. Attach Pelvis Servos to Front Body Bracket


Parts required:

No. 5	No. 7	
HSR8498HB2R200	HSR8498HB2L200	HR1B-0006
1 pc	1 pc	1 pc


Place the components so they match the picture.



Remove the splined horn from each servo. Remove the two outside black screws from the splined horn side of each servo.






Attach the front body bracket to the servos using the previously removed screws. Once in place, reinstall the splined horns.




C. Attaching the Shoulder to the Front Body Bracket


Parts required:

		
Shoulder assembly	Pelvis assembly	PH/M 2 x 4mm
2 sets	1 set	8 pcs

Layout the parts so they match the picture. Notice the orientation of the servo cables.







Connect the two shoulders to the front body bracket using four PH/M 2 x 4mm screws per shoulder. Use the picture for proper screw placement.




D. Attaching the Back Body Bracket to the Front Body Assembly


Parts required:

			
Front body assembly	HR1B-0005	Support 3 x 5mm	PH/M 2 x 4mm
1 set	1 pc	4 pcs	6 pcs


Install the four controller supports at the locations shown in the picture.




Remove the idler horns from the pelvis servos. Remove the two silver screws from the outer edge of each pelvis servo. Set two screws aside for later use.



Place the back body bracket over the front body assembly and route the cables as shown in the picture.






Using the picture as a guide, attach the back body cover to the front assembly with six PH/M 2 x 4mm screws. Reinstall two of silver case screws previously removed. Do not install screws at the locations noted in the picture. Reattach the idler horns to the pelvis servos.



E. Outer Shoulder Assembly

Parts required:


		
Body assembly	HR1B-0001	PH/T-2 2 x 4mm
1 set	2 pcs	8 pcs

This picture shows the position of the outer shoulder brackets to the body.




Place the brackets as shown in the picture. Note the hole locations.

Using the picture as a guide, attach the brackets to the splined horns of the inner shoulders with four screws each. The number 1 on the splined horn is at 12 o'clock for both shoulders.




The completed shape of the body.

**5. Attaching the Legs and Arms to the Body****A. Attaching the Legs to the Body**



Parts required:

		
Body assembly	Leg assembly	PH/T-2 2 x 4mm
1 set	2 sets	14 pcs


Arrange the body and legs so they match the picture.



Attach the legs by inserting screws in the splined and idler horns.






Using the picture as a reference, align the thigh bracket over the pelvis horns. The number 5 on the splined horn of both servos is at 12 o'clock.





Do not place screws in the idler horns at the 9 o'clock position of the right leg and the 3 o'clock position of the left leg.

B. Attaching the Arms to the Body

Parts required:


		
Body assembly	Arm Assembly	PH/T-2 2 x 4mm
1 set	2 sets	14 pcs

Arrange the body and arms so they match the picture.



Using the picture as a reference, align the shoulder bracket over the splined and idler horns of the bicep. For the right bicep, the number 7 on the splined horn is a 12 o'clock. The number 3 is at 12 o'clock on the left bicep.











Secure the bracket to biceps with four PH/T-2 2 x 4mm screws in each splined horn and three in each idler horn. Do not insert a screw at the 12 o'clock position of the idler horn.





Completed body.

6. Attaching the Head to the Body

Parts required:

				
HR1B-0007	HR1C-0003	HR1C-0004	HR1C-0005	LED Module
1 pc	1 pc	1 pc	1 pc	1 pc
				
HSR8498HA2	PH/M-2 2 X 4mm	PH/T-2 2 X 5mm	PH/M 2.6 x 4mm	PH/T-2 2 x 8mm
1 pc	2 pcs	2 pcs	10 pcs	6 pcs

Attach the HSR8498HA2 servo horn to the upper body bracket with four PH/T-2 2 x 8mm screws using the pictures as a reference.



Disconnect the LED board from the controller and attach it to the back of the visor with the two PH/M-2 2 x 4mm screws.


Snap the visor into the front half of the head. Use the pictures as a guide.




Secure the upper body bracket to the body using the ten PH/M 2.6 x 4mm screws.




To insure a proper fit, start in the corners first, then move on to the other hole positions.



Attach the front head half to the horn on the upper body with two PH/T 2 x 8mm screws. This picture shows the general screw locations.






Attach the back head half to the front with the two PH/T-2 2 x 5mm screws





The completed head assembly.

7. Attaching the Front Body Cover

Parts required:

		
Robot Assembly	HR1C-0001	PH/T-2 2 x 5mm
1 set	1 pc	2 pcs

The front body cover is attached to the main body with the two PH/T-2 2 x 5mm screws. This picture shows the hole locations of the front body cover.






Place the front body cover over the front of the body and using a long phillips head screwdriver, insert the screws through the back of the robot.

Assembled front body cover.




8. Attaching the Controller to the Robot:


Parts required:

		
Robot assembly	MR-C3024	PH/M 3 x 4mm
1 set	1 pc	4 pcs

Use the PH/M 3 x 4mm screws to secure the MR-C3024 controller to the already installed stand offs in the back of the robot. Before installing, lay the shoulder and pelvis servo cables to each side.



At this time it would be a good idea to double check all joints for proper movement. By hand, move each joint to check for 180 degrees of travel.




9. Cable Arrangement



The Robonova-1 has 16 cables that must be connected to the controller. To prevent mishaps and for proper operation, it is important that the cables are secured neatly to the body. This section will describe the cable installation and the use of the cable clamps and ties.

A. Insert Cables into the Controller


Lay the robot carefully on its front and separate the cables to ease installation.



This picture details the servo cable placement. The numbers on the servos represent their assigned slot in the controller.




Here is a detailed diagram showing the assigned pins in the controller.



It is important that the cables are connected to the controller board with the correct polarity. The gray wire on the cable is the signal wire and should always face in towards the center of the board. The plastic pin housing of the cable is keyed on the signal wire side to assist in assembly.

Insert the cables into the controller board.









B. Installing the Cable Clamps


The cable clamps protect the cables from damage when the robot is moving and prevents them from interfering with any movement.

****Completely review this section before beginning.****

Parts required:

				
Robot Assembly	PH/T-2 2 x 4mm	Washer	PH/M 2 x 4mm	Lug
1 set	12 pcs	24 pcs	2 pcs	2 pcs
				
Cable Clamp				
24 pcs				

Exam the picture of the arms and note the locations marked. Each location will have a cable clamp attached.




The screws used are:

#1 = Removed long silver servo case screw. (These were set aside earlier during construction.)

#2 = PH/T-2 2 x 4mm

#3 = Removed long silver servo case screw.

#4 = PH/T-2 2 x 4mm



The leg screw locations are shown in the pictures. The screws used are:

#1 = PH/T-2 2 x 4mm

#2 = Removed long silver servo case screw.

#3 = PH/T-2 2 x 4mm

#4 = Removed long silver servo case screw.

#5 = Removed short silver servo case screw.

#6 = PH/T-2 2 x 4mm


Add the cable clamps to the legs first. Begin at the number one location on the left leg. Slide a washer over the screw. Then wrap the clamp around the cable and insert the screw into the holes of the clamp. Insert the screw into location number one and tighten. Continue the same process through location number six. Perform the same steps for the right leg. .




On the arms add a clamp to the number one and two locations. Before adding a clamp to the number three position, it is necessary to add a lug to the bicep servo cables. On the right arm this is servo No. 4 and on the left arm this is servo No. 2. Following the pictures, loosely bend the lug around the cable.



Once the lug is in place, complete the clamp assembly using the pictures as a reference.






Left Arm

Completed lug and clamp assembly for the number three position. Finish the arms by adding a clamp to the number four position.


Add clamps to the main body at the locations shown in the pictures. At the number one position use a PH/T-2 2 x 4mm screw. All cables from the leg are held with this clamp.

The number two position uses the removed silver servo case screws. This clamp also holds the cables from the leg.


The number three position uses a PH/M 2 x 4mm screw. Use this clamp to hold the cables from the arm.



Right side



Left side



Left Arm

Right Arm



Body
Back View

Left Leg


Right Leg

C. Cable Tie Assembly


Parts required:

	
Robot Assembly	Cable Tie
1 set	8 pcs


To reduce stress to individual cables it is necessary to add cable ties at key locations. Add a cable tie to each arm section as shown in the picture.



Bundle the wires close to the controller and use a cable tie to keep them together. Use the picture as an example.





Add cable ties to each leg at the locations shown in the picture.




Completed cable tie assembly.

10. LED and IR Connection

Parts required:

	
Robot assembly	IR Sensor
1 set	1 pc

Plug the LED's white plug into the controller as shown in the picture.




Disconnect the servo cable plugged into the number 8 slot of the controller. Remove the pin cover from the controller. At this time, do not reinstall the servo cable.

To add the IR sensor it is necessary to cut a slot in the protective pin cover for the sensor plug. The slot should be cut so the sensor can plug into the AD 7 port.




Once the cover is cut, place the cover back onto the controller.




For the solid fix of IR sensor, you can use 5-minute Epoxy (Araldite) adhesive.



Open the back body cover at the RN-1




Insert the connector of the IR Sensor into "AD7" port which located in upper right side of MR-C3024 controller.




Before inserting the connector, remove the pin cover from the MR-C3024 and cut away part of the pin cover.



Reattach the pin cover.




Connect the IR Sensor to the MR-C3024.
The Dark gray wire of the connector must be at the bottom.




Open the back head cover with removing 2 screws and cut 1 X 8mm(0.04 X 0.3in.) sized rectangular hole on the upper side of front head cover with art knife or file (Refer to photo).




With Epoxy adhesive, apply mix to joint surface (between IR sensor and upper side of front head cover) and assemble parts.
Read "How to use" instruction of Epoxy glue in advance.



After assemble parts, hold together with Tape or Rubber band for 10~15 minutes.



Reattach the back head cover to the front head cover with two PH/T 2X5mm screws. The shape of IR sensor.



The next step is the remocon programming setup. Open roboBASIC and either create a new file or open action_auto.bas found in the templet folder of the CD.

In the template program find 'A = REMOCON(0) and change it to A = REMOCON(1)


```

MAIN1
A = REMOCON(1)
A = A - 10
ON A GOTO Y&IN.X1.X2.X3.X4.X5.X6.X7.X8.X9.X10.X11.X12.X13.X14.X15.X16.X17.X18.X19.X20
GOTO HALF
    
```

Connect the ROBONOVA-I to a PC with the Serial Interface cable.







Click the "Run All" (integrated execution) button to upload to the controller.



11. Final Assembly

A. Install Back Body Cover

Parts required:

			
Robot assembly	HR1C-0002	PH/T-2 2 x 26mm	PH/M 2.6 x 4mm
1 set	1 pc	2 pcs	2 pcs

Place the back body cover over the controller. Make sure that there are no pinched wires. For a proper fit, snap the top of the front cover into the back cover. Install the two PH/T 2 x 26mm screws in the top holes of the cover and tighten. Use the two PH/M 2.6 x 4mm screws to secure the lower body cover to the robot frame.








Completed back cover.




B. Battery Installation


Parts required:

				
Robot Assembly	HR1B-0008	NiMH Battery Pack	Thumb Screw	Battery Wire Protector
1 set	1 pc	1 pack	2 pcs	1 pc



Slide the battery wire protector into place as shown in the pictures.



Insert the battery into the bottom of the robot as shown in the picture.



Attach the battery cover plate as shown.



Install the two thumbscrews through the holes in the battery plate to secure it to the robot frame.

Plug the battery into the battery terminal of the controller.



Completed Robonova-1



12. Charging

To charge the battery, plug the charger's charge connector into the controller and then into a wall socket.





The charger has a red LED indicating that it is charging. When finished (roughly 1 hour) the LED will turn green. At this time it is ok to disconnect the charger from the robot and the wall socket.

*****While the charger is plugged into the robot, do not switch the robot on. Running the robot while the charger is connected may result in damage to the controller or servos.*****

13. Personalizing

The Robonova-1 kit comes with four different sets of stickers to personalize the robot.



The sticker sets include number stickers that can be used to label each servo cable for quick identification.

V. Quickstart

To get the robot up and running quickly, using the following quickstart guide. This guide will demonstrate how to set the Robonova-1 up for use with the remocon. More in depth details of the software can be found in section VI

1. About RoboBASIC.

RoboBASIC is an educational language based on the BASIC programming language. It is designed to be specifically used with the MR-C family of robot controllers. Through enhancements, it allows for the control and operation of robots.


RoboBASIC is compatible with Windows™ 98, ME, 2000 and XP.

The software version on the CD may vary from previous versions. The software, along with the manual may be changed without notice. To obtain the latest version, go to the Hitec Robotics website at www.hitecrobotics.com.

RoboBASIC, RoboSCRIPT, and RoboREMOCON are registered software, making it illegal to reproduce or distribute the software or manual without permission.


2. Installing the software

A. Installation Procedure




The setup program will ask for a destination folder. Either accept the default destination or create an alternative one. Click the "Next" button to proceed.


Open the RoboBASIC folder found on the CD. Select the proper language folder and run the "setup.exe" program. When RoboBASIC is installed, the programs RoboREMOCON and RoboSCRIPT will also be installed.




Click "Next" to continue the installation or "Cancel" to stop.



The installation progress.





Installation complete. Select "Close" to exit.



B. Setup

After the program has been installed, it is necessary to select the serial port and controller type being used.

Open the RoboBASIC program by either double clicking the desktop icon or selecting it from the start menu. Once open move to "Set" on the menu bar. Select "Set Port".



Set the port to the one specified in the Windows™ operating system and click on OK.

3. Upload the Template Program


Included on the CD is a program named "Overall_Template_Program.bas". This program contains many routines and commands that allows the robot to be controlled immediately after it is uploaded. The program is located in the "template Program for roboBASIC" folder.

If the CD is not already loaded in the CD drive of the PC, do so now. Attach the 9 pin DIN plug of the included serial cable to the serial port of the PC. Plug the mini jack into the Robonova-1. At this time, do not turn the robot on.




Open RoboBASIC by clicking on the desktop icon or selecting Start/All Programs/RoboBASIC.


Select file on the menu bar.




Click on "Open Program File"



In the Open Program File window go to the CD drive and open the "template Program for roboBASIC" folder. In the file list select Overall Template Program.bas and click on the open button.




The template will open in the Editor window.



Run All Button

Place the robot face down on a flat surface and turn it on. When turned on, the robot will play a melody and move to the standard position. The blue head LED will be on indicating that it is receiving power. Click the "Run All" button on the RoboBASIC tool bar.

The Compiling window will open and show the program's compiling status.




Once compiled, the Download window will appear. Click on the ok button.

The Download window will change to show the status of the upload. When complete, the Robonova-1 will reboot and play the music.

4. Zero Settings

After the template program has been loaded into the controller of the robot, it might be noticed that some of the servos are slightly out of alignment. To correct this, it is necessary to adjust their zero points settings. The robot must be connected to the serial cable and turned on during this process.

Begin by selecting "Set Zero Point" under the header "Compile" in the menu bar.




This opens the Robonova Zero Set window. The window contains a picture of the robot with numbers and arrows near each joint.

Click on the "Read Settings" button. Be careful when performing this operation because the robot will immediately begin moving to the same position as the one in the window. It is best to lay the robot on its back before clicking on the button. After the robot initializes, stand it up on a flat surface.




The RoboNova-1 is set properly when it matches the following pictures.

The feet should be flat on the surface.




The ankle and hip brackets should be in a straight line.




The legs should be 8mm apart and the hip bracket in line with the body.



The arms should be in a flat horizontal position.



If a servo is not aligned properly, locate it in the Zero Set window and make adjustments using the up or down arrows.



When all the servos are in the correct position, click on the "Write Settings" button. This will install the zero settings into the controller's RAM bypassing the template program. Regardless of any changes to the template or when creating a personal program, the zero settings will be saved.

The progress line gives a visual representation of the upload.



When complete, close the window and turn the robot off then back on. It should now resemble the pictures.



5. Operating the ROBONOVA-1

The kit includes an IR remocon to control the robot remotely(Kit W/Remocon & RTW only).
The template program that was previously loaded contains motions that are assigned to each button of the remocon.
The following table lists the motions and their key assignments.

Key	Motion
Power	On: Motor on → Basic Position / Off: Sitting position → Motor off
1	Bow
2	Raise Arms
3	Sit
4	Sit → Raise Arms
5	Raise Leg
6	Spread Legs → Extend Arms → Right/Left Tilt
7	Flap like a bird
8	Kick
9	Handstand
0	Fast Forward Walk
*	Turn Left
#	Turn Right
▲	Walk Forward
◀	Step Left
■	Sit ↔ Stand up
▶	Step Right
▼	Walk Backward
△	Front Tumble
◁	Left Cartwheel
□	Front Punch
▷	Right Cartwheel
▽	Backward Tumble
A	Attack Left
B	Attach Right
C	Left Front Attack
D	Right Front Attack
E	Play 'C' Note (spare)
F	Play 'D' Note (spare)
G	Play 'E' Note (spare)

To get the Robonova-1 to perform a motion, point the remocon at the IR receiver and press the corresponding button.
Range may be affected by ambient light, so it is best not to operate the robot in bright conditions.


VI. Software Overview

The following sections are designed to provide the beginner with a general understanding of the included software.

1. Operational Overview of RoboBASIC

A. RoboBASIC Windows

When RoboBASIC is opened there are two windows opened by default. One is the Assist Window the other is the Editor Window.
The Assist Window is a PC file directory. Use the directory to locate previously created programs or to open a program from the CD.
Only files with the extension *.bas and *.rsf can be opened and saved. All codes and routines are created and viewed within the Editor Window.



B. Menu and Tool Bars

All operations can be performed by using the menu bar.




The tool bars perform most of the functions of the menu bar. By placing the mouse pointer over a button, its function will be displayed.



C. Program Creation

All programming takes place within the Editor Window. With RoboBASIC, it is possible to type specific codes for sensors, remote control, and motions. Explanations of all the commands used in RoboBASIC are found on the CD in the "RoboBASIC Command Instruction Manual" folder.

The tools most helpful to beginners with little programming experience are the "Servo Motor Real-Time Control" and "Robonova Motor Control". These tools allow the creation of movements. No programming experience is required.



Template.bas as shown in the Editor window.

1) Servo Motor Real-Time Control

To create a movement with the Servo Motor Real-Time Control window, select it from either the menu bar or the tool bar. Unless the robot is turned on and connected to the serial port this window will not open.



Servo Motor Real-Time Control button.




Select from the Menu bar


The Servo Motor Real-Time Control window allows the user to control the servos in the robot with the dials. When opened the window will have either four groups of six dials or three groups of eight dials. To switch between the two, select the grouping button.

Since the Robonova is separated into four motor groups, use the G6 screen.


The dials correspond to each servos position on the controller. Each row of dials is a motor group. Each dial has a range from 10~190 representing 180 degrees of servo throw.




This picture shows Motor 0, which is the servo plugged into the S0 pins of the controller. It is also in motor group A.




There are a two ways to control the servos directly. The first is to click and hold the left mouse button on the needle of a dial. By moving the mouse left or right the needle will follow, which in turn will move that specific servo.



The second way is to click on the arrows to the right and left of the numeral under the dial.



When all dials have been moved to the desired position, click on the "Move Insert" button for each group. This will insert the command **MOVE** with the motor groups position into the editor window. Example: MOVE G6A, 100, 76, 145, 93, 100,100




2) Robonova Motor Control


The Robonova Motor Control is specifically designed for use with the Robonova-1 robot. To open the window, select it from the Menu Bar or the tool bar. Unless the robot is turned on and connected to the serial port this window will not open.



Robonova Motor Control Button




Select from the Menu Bar



The window that pops up has a picture of the robot and buttons to the left of the picture. Each joint of the robot is labeled with the servo number and current position.


By moving the mouse pointer over the joint, a drop down box will appear. Within the box are the controls for moving that servo.

The single arrows move the servo in single increments and the dual in increments of five. The slider below the arrows also moves the servo.



The buttons to the left of the Robonova allow positions to be copied from one arm or leg to the other, enabling or disabling the servos, and capturing the servo positions. The latter two functions will be covered in the next section.


The important buttons at the moment are the ones located at the bottom. These are the MOVE insert and Close buttons. They function in the same manner as the Servo Motor Real Time Control except for some minor differences. To the left of the Insert button are two check boxes. This allows the choice of either inserting the MOVE command in servo groups of six or one twenty-four servo group.



The smaller Close button inserts the WAIT command. This command should be inserted after the Move commands. A further explanation for the command can be found on the CD in the RoboBASIC Command Instruction Manual folder. The larger Close button exits the window.




D. Catch and Play

One of the most exciting features of RoboBASIC is "Catch and Play". This function is similar to key framing used in animation. The robot is moved to a position by hand, the position saved and then the robot is moved to the next position. Each position creates a key. When the keys are put together, the in-between movements are automatically added, creating fluid motion.



To perform the "Catch and Play" functions, the robot must be connected to the serial adapter and RoboBASIC running. Then either the "Servo Motor Real-Time Control" or the "Robonova Motor Control" window must be opened.



In the "Servo Motor Real-Time Control" window each servo number has a check box next to it. If the box is checked, then the servos are directly controlled by the program. If the box is unchecked, then that particular servo moves freely and can be positioned by hand. Once the box is rechecked, the dial will go directly to the position the servo was moved to.



The boxes for an entire servo group can also be checked or unchecked using the "Select All" box.

Once all the servo groups have been moved to the desired position, follow the steps previously mentioned to insert the positions into the editor window.


Performing "Catch and Play" in the "Robonova Motor Control" window is very similar. Next to each servo number in the picture are the same check boxes.



The "Group Enable" functions the same as the "Select All" mentioned before.

E. Uploading a File


Once a routine is finished it is time to upload the program into the controller. To do this the program must first be compiled into object code. Only then can it be uploaded.



With the program loaded into the Editor window, it can be compiled by selecting "Compile" from the menu bar or by clicking on the "Make Object Code" button.



Compile tool bar button



The program will show the status of the process. If there is an error in the code, RoboBASIC will switch to Debug mode and show the line requiring correction.



More information on Debugging can be found on the CD in the RoboBASIC Command Instruction Manual folder.





After the program has been compiled, it is time to upload to the controller. This is accomplished by either selecting "Download" from the menu bar header "Compile" or clicking on the "Download" button in the tool bar.



Download tool bar button

Click on OK to continue in the Download window.




The program will show the progress of the upload.

Both the compiling and upload can be simultaneously started by either clicking on the "Run All" button on the tool bar or selecting this option under the header "Compile" in the menu bar.



Run All tool bar button



F. Further Resources


It is highly recommended that the RoboBASIC Command Instruction Manual found on the CD be reviewed. The Manual will explain all the commands used in RoboBASIC and provide brief examples.

This operational overview section explained in basic terms how to get around and use RoboBASIC. Some functions were not mentioned at all. These functions with more detailed explanations will be found in following sections, but first it is important to become familiar with the two other programs that were installed at the same time as RoboBASIC.


4. RoboSCRIPT

RoboSCRIPT allows routines to be created without any programming experience. Once a motion routine is created, it can be saved and uploaded to the robot controller.

A. Initial Setup




RoboSCRIPT is setup in the same manner as RoboBASIC. On the menu bar, go to the header "Set" and click on "Set Port".



The port setting window is identical to RoboBASIC. Select the COM port currently being used and click OK.

B. RoboSCRIPT Windows




There are three main windows in RoboSCRIPT.

The Assist window is a PC file directory. Use the directory to locate previously created programs or to open a program from the CD. Only files with the extension *.rsf can be opened and saved.

The Motor Window is composed of sliders that directly control the servos. For ease of operation, the sliders are grouped according to their location in the robot.


The Edit window is where motions are saved and basic controls are set.

On the left hand side of the Edit window are command buttons that allow movements to be slightly modified. Detailed explanations of each command are found in the RoboBASIC Command Instruction Manual on the CD.



C. Script Creation

Creating a script for the robot is as simple as moving the sliders for each corresponding servo.




After the servos have been positioned, click on the "Insert Move" button. This will create a new line in the Edit window.




During the creation, delays and servo speeds can be added. For more information on Delay and Speed refer to the CD in the RoboBASIC Command Instruction Manual folder. Continues this process until the entire routine has been created.

To test the routine, click on the "Run" button.




D. Uploading and Saving a Script




To upload an open routine, go to the header "Controller" on the menu bar and select "download". This will install the routine to the controller.

The download window will pop up. Select OK to begin the upload.





To save a script to disk go to the header "File" on the menu bar and selecting either "Save Program File" or "Save As...".

E. Using a RoboSCRIPT File in RoboBASIC




After a routine has been created in RoboSCRIPT, it can be copied and pasted into RoboBASIC. To do this, with the script open, click on the Copy button.

Once copied, it can be pasted into RoboBASIC by going to the "Edit" header on the menu bar and selecting "paste". This will paste the routine into the edit window of RoboBASIC.



It is also possible to open saved script files directly within RoboBASIC with "Open Program File" under the "File" header. Once the window appears, change the file type to "ROBOScript Program (*.rsf)" and select the file to open.

Before the pasted or opened script can be used in roboBASIC, the following commands must be added:
GETMOTORSET G24,1,1,1,1,1,0,1,1,1,0,0,0,1,1,1,0,0,0,1,1,1,1,1,0
SPEED 5
MOTOR G24




3. RoboREMOCON

The RoboREMOCON allows direct control of the robot from a PC via the included serial adapter. The buttons correspond to the assigned keys found in the template program previously uploaded. If desired, RoboSCRIPT files can be assigned to a particular button instead.

A. Port Setting




Before the robot can be controller, a COM port must be selected. Click on the "Setting Port" button and the "Port Setting Window" will open. Follow the steps mentioned in previous sections to set the port.

B. Setting Buttons





The RoboREMOCON has 32 different buttons that can be setup to control different routines within the robot. To assign a button to a specific routine, click on the "Setting Buttons" button.

This will open Setting Buttons window. In this window, each button can be assigned a Label, File and brief description.




Click on one of the buttons to the left of the window.

When clicked the "Set" widow will appear.




The label changes the button display from the number to whatever is typed in the label box. If the label is too large, only a portion of it will appear. For ease of use, match the label to the remocon. For example: The #16 button on the remocon is the power button. So it could be called "On".

In the RSF file box, select the routine that the button will control. Only files with the *.rsf extension can be used.




In the Tag box, a description can be added if so desired. This will create a pop-up box when the mouse pointer is moved over a button.

When finished, click on the OK button to close.




C. Uploading to the Controller

After RoboREMOCON has been set up, the instructions can be uploaded to the controller.



In the Setting Buttons window, two download types are listed. Select PC control if the robot is to be controlled directly via RoboREMOCON from a PC. For this to work, the robot must be connected to the serial cable.

If the Hitec remocon is being used, select "IR Remote control".




Click on the "Download" button to upload to the controller.

VII. Programming the ROBONOVA-1

1. Template Program

Included on the CD is a file called the "overall_template_program.bas". This file contains many factory set routines and commands that can be used immediately after it is uploaded to the controller without any extra programming required. The file is found on the CD in the "Template Program for roboBASIC" folder.



A. Overview of the Template Program


The program is broken into different sections for ease of use. The sections are the basic program commands, Main, and the motion routines. Only general explanations will be given here, further details are found in the RoboBASIC Command Instruction Manual found on the CD.

1) Commands, Variables and Constants

This section contains the commands necessary for the robot to operate properly.

GOTO AUTO

This command tells the controller to move to the template program



DIM declarations

These declarations set the variables used within the program.

CONST ID

This is the ID assigned to the Robonova-1 and is used in conjunction with the REMOCON command found in the Main1 subroutine.



It is possible to have four Robonovas and remocons in use at the same time. To do this each is given a separate ID, between 1 and 4, so they do not interfere with each other. To change the Robot ID, use the code in the table.

CONST_ID	Remocon
0	1
32	2
64	3
96	4




The remocon must also be set to the right ID. To change the ID in the remocon, press the P1 button and the correct ID number (1 ~ 4) and hold for two seconds.

Example, CONST_ID = 32 will work with a remocon set to channel 2.

IF...THEN, RR variable

These lines are for use with RoboREMOCON. If the serial adapter is attached to the robot, the robot turned on, and RoboRemocon is open on the PC, it is possible to control the robot directly from the PC.



There is no need to setup RoboREMOCON first. It will operate in the same manner as the remocon.

PTP, DIR, GETMOTORSET, and MOTOR

These commands set controls for the servos in the robot.

Refer to the RoboBASIC Command Instruction Manual found on the CD for more information on their usage.

```
0324 DEF SERVO
0325 DEF A=100
0326
0327 '--- Servo 1: 180° (180°) ---
0328 DEF S1A : 180,1,0,0
0329 DEF S1B : 180,1,0,0
0330 DEF S1C : 180,1,0,0
0331
0332 '--- Servo 2: 180° (180°) ---
0333 DEF S2A : 180,1,0,0
0334 DEF S2B : 180,1,0,0
0335 DEF S2C : 180,1,0,0
0336
0337 '--- Servo 3: 180° (180°) ---
0338 DEF S3A : 180,1,0,0
0339 DEF S3B : 180,1,0,0
0340 DEF S3C : 180,1,0,0
0341
0342 '--- Servo 4: 180° (180°) ---
0343 DEF S4A : 180,1,0,0
0344 DEF S4B : 180,1,0,0
0345 DEF S4C : 180,1,0,0
0346
0347 '--- Servo 5: 180° (180°) ---
0348 DEF S5A : 180,1,0,0
0349 DEF S5B : 180,1,0,0
0350 DEF S5C : 180,1,0,0
0351
0352 '--- Servo 6: 180° (180°) ---
0353 DEF S6A : 180,1,0,0
0354 DEF S6B : 180,1,0,0
0355 DEF S6C : 180,1,0,0
0356
0357 '--- Servo 7: 180° (180°) ---
0358 DEF S7A : 180,1,0,0
0359 DEF S7B : 180,1,0,0
0360 DEF S7C : 180,1,0,0
0361
0362 '--- Servo 8: 180° (180°) ---
0363 DEF S8A : 180,1,0,0
0364 DEF S8B : 180,1,0,0
0365 DEF S8C : 180,1,0,0
0366
0367 '--- Servo 9: 180° (180°) ---
0368 DEF S9A : 180,1,0,0
0369 DEF S9B : 180,1,0,0
0370 DEF S9C : 180,1,0,0
0371
0372 '--- Servo 10: 180° (180°) ---
0373 DEF S10A : 180,1,0,0
0374 DEF S10B : 180,1,0,0
0375 DEF S10C : 180,1,0,0
0376
0377 '--- Servo 11: 180° (180°) ---
0378 DEF S11A : 180,1,0,0
0379 DEF S11B : 180,1,0,0
0380 DEF S11C : 180,1,0,0
0381
0382 '--- Servo 12: 180° (180°) ---
0383 DEF S12A : 180,1,0,0
0384 DEF S12B : 180,1,0,0
0385 DEF S12C : 180,1,0,0
0386
0387 '--- Servo 13: 180° (180°) ---
0388 DEF S13A : 180,1,0,0
0389 DEF S13B : 180,1,0,0
0390 DEF S13C : 180,1,0,0
0391
0392 '--- Servo 14: 180° (180°) ---
0393 DEF S14A : 180,1,0,0
0394 DEF S14B : 180,1,0,0
0395 DEF S14C : 180,1,0,0
0396
0397 '--- Servo 15: 180° (180°) ---
0398 DEF S15A : 180,1,0,0
0399 DEF S15B : 180,1,0,0
0400 DEF S15C : 180,1,0,0
0401
0402 '--- Servo 16: 180° (180°) ---
0403 DEF S16A : 180,1,0,0
0404 DEF S16B : 180,1,0,0
0405 DEF S16C : 180,1,0,0
0406
0407 '--- Servo 17: 180° (180°) ---
0408 DEF S17A : 180,1,0,0
0409 DEF S17B : 180,1,0,0
0410 DEF S17C : 180,1,0,0
0411
0412 '--- Servo 18: 180° (180°) ---
0413 DEF S18A : 180,1,0,0
0414 DEF S18B : 180,1,0,0
0415 DEF S18C : 180,1,0,0
0416
0417 '--- Servo 19: 180° (180°) ---
0418 DEF S19A : 180,1,0,0
0419 DEF S19B : 180,1,0,0
0420 DEF S19C : 180,1,0,0
0421
0422 '--- Servo 20: 180° (180°) ---
0423 DEF S20A : 180,1,0,0
0424 DEF S20B : 180,1,0,0
0425 DEF S20C : 180,1,0,0
0426
0427 '--- Servo 21: 180° (180°) ---
0428 DEF S21A : 180,1,0,0
0429 DEF S21B : 180,1,0,0
0430 DEF S21C : 180,1,0,0
0431
0432 '--- Servo 22: 180° (180°) ---
0433 DEF S22A : 180,1,0,0
0434 DEF S22B : 180,1,0,0
0435 DEF S22C : 180,1,0,0
0436
0437 '--- Servo 23: 180° (180°) ---
0438 DEF S23A : 180,1,0,0
0439 DEF S23B : 180,1,0,0
0440 DEF S23C : 180,1,0,0
0441
0442 '--- Servo 24: 180° (180°) ---
0443 DEF S24A : 180,1,0,0
0444 DEF S24B : 180,1,0,0
0445 DEF S24C : 180,1,0,0
0446
0447 '--- Servo 25: 180° (180°) ---
0448 DEF S25A : 180,1,0,0
0449 DEF S25B : 180,1,0,0
0450 DEF S25C : 180,1,0,0
0451
0452 '--- Servo 26: 180° (180°) ---
0453 DEF S26A : 180,1,0,0
0454 DEF S26B : 180,1,0,0
0455 DEF S26C : 180,1,0,0
0456
0457 '--- Servo 27: 180° (180°) ---
0458 DEF S27A : 180,1,0,0
0459 DEF S27B : 180,1,0,0
0460 DEF S27C : 180,1,0,0
0461
0462 '--- Servo 28: 180° (180°) ---
0463 DEF S28A : 180,1,0,0
0464 DEF S28B : 180,1,0,0
0465 DEF S28C : 180,1,0,0
0466
0467 '--- Servo 29: 180° (180°) ---
0468 DEF S29A : 180,1,0,0
0469 DEF S29B : 180,1,0,0
0470 DEF S29C : 180,1,0,0
0471
0472 '--- Servo 30: 180° (180°) ---
0473 DEF S30A : 180,1,0,0
0474 DEF S30B : 180,1,0,0
0475 DEF S30C : 180,1,0,0
0476
0477 '--- Servo 31: 180° (180°) ---
0478 DEF S31A : 180,1,0,0
0479 DEF S31B : 180,1,0,0
0480 DEF S31C : 180,1,0,0
0481
0482 '--- Servo 32: 180° (180°) ---
0483 DEF S32A : 180,1,0,0
0484 DEF S32B : 180,1,0,0
0485 DEF S32C : 180,1,0,0
0486
0487 '--- Servo 33: 180° (180°) ---
0488 DEF S33A : 180,1,0,0
0489 DEF S33B : 180,1,0,0
0490 DEF S33C : 180,1,0,0
0491
0492 '--- Servo 34: 180° (180°) ---
0493 DEF S34A : 180,1,0,0
0494 DEF S34B : 180,1,0,0
0495 DEF S34C : 180,1,0,0
0496
0497 '--- Servo 35: 180° (180°) ---
0498 DEF S35A : 180,1,0,0
0499 DEF S35B : 180,1,0,0
0500 DEF S35C : 180,1,0,0
0501
0502 '--- Servo 36: 180° (180°) ---
0503 DEF S36A : 180,1,0,0
0504 DEF S36B : 180,1,0,0
0505 DEF S36C : 180,1,0,0
0506
0507 '--- Servo 37: 180° (180°) ---
0508 DEF S37A : 180,1,0,0
0509 DEF S37B : 180,1,0,0
0510 DEF S37C : 180,1,0,0
0511
0512 '--- Servo 38: 180° (180°) ---
0513 DEF S38A : 180,1,0,0
0514 DEF S38B : 180,1,0,0
0515 DEF S38C : 180,1,0,0
0516
0517 '--- Servo 39: 180° (180°) ---
0518 DEF S39A : 180,1,0,0
0519 DEF S39B : 180,1,0,0
0520 DEF S39C : 180,1,0,0
0521
0522 '--- Servo 40: 180° (180°) ---
0523 DEF S40A : 180,1,0,0
0524 DEF S40B : 180,1,0,0
0525 DEF S40C : 180,1,0,0
0526
0527 '--- Servo 41: 180° (180°) ---
0528 DEF S41A : 180,1,0,0
0529 DEF S41B : 180,1,0,0
0530 DEF S41C : 180,1,0,0
0531
0532 '--- Servo 42: 180° (180°) ---
0533 DEF S42A : 180,1,0,0
0534 DEF S42B : 180,1,0,0
0535 DEF S42C : 180,1,0,0
0536
0537 '--- Servo 43: 180° (180°) ---
0538 DEF S43A : 180,1,0,0
0539 DEF S43B : 180,1,0,0
0540 DEF S43C : 180,1,0,0
0541
0542 '--- Servo 44: 180° (180°) ---
0543 DEF S44A : 180,1,0,0
0544 DEF S44B : 180,1,0,0
0545 DEF S44C : 180,1,0,0
0546
0547 '--- Servo 45: 180° (180°) ---
0548 DEF S45A : 180,1,0,0
0549 DEF S45B : 180,1,0,0
0550 DEF S45C : 180,1,0,0
0551
0552 '--- Servo 46: 180° (180°) ---
0553 DEF S46A : 180,1,0,0
0554 DEF S46B : 180,1,0,0
0555 DEF S46C : 180,1,0,0
0556
0557 '--- Servo 47: 180° (180°) ---
0558 DEF S47A : 180,1,0,0
0559 DEF S47B : 180,1,0,0
0560 DEF S47C : 180,1,0,0
0561
0562 '--- Servo 48: 180° (180°) ---
0563 DEF S48A : 180,1,0,0
0564 DEF S48B : 180,1,0,0
0565 DEF S48C : 180,1,0,0
0566
0567 '--- Servo 49: 180° (180°) ---
0568 DEF S49A : 180,1,0,0
0569 DEF S49B : 180,1,0,0
0570 DEF S49C : 180,1,0,0
0571
0572 '--- Servo 50: 180° (180°) ---
0573 DEF S50A : 180,1,0,0
0574 DEF S50B : 180,1,0,0
0575 DEF S50C : 180,1,0,0
0576
0577 '--- Servo 51: 180° (180°) ---
0578 DEF S51A : 180,1,0,0
0579 DEF S51B : 180,1,0,0
0580 DEF S51C : 180,1,0,0
0581
0582 '--- Servo 52: 180° (180°) ---
0583 DEF S52A : 180,1,0,0
0584 DEF S52B : 180,1,0,0
0585 DEF S52C : 180,1,0,0
0586
0587 '--- Servo 53: 180° (180°) ---
0588 DEF S53A : 180,1,0,0
0589 DEF S53B : 180,1,0,0
0590 DEF S53C : 180,1,0,0
0591
0592 '--- Servo 54: 180° (180°) ---
0593 DEF S54A : 180,1,0,0
0594 DEF S54B : 180,1,0,0
0595 DEF S54C : 180,1,0,0
0596
0597 '--- Servo 55: 180° (180°) ---
0598 DEF S55A : 180,1,0,0
0599 DEF S55B : 180,1,0,0
0600 DEF S55C : 180,1,0,0
0601
0602 '--- Servo 56: 180° (180°) ---
0603 DEF S56A : 180,1,0,0
0604 DEF S56B : 180,1,0,0
0605 DEF S56C : 180,1,0,0
0606
0607 '--- Servo 57: 180° (180°) ---
0608 DEF S57A : 180,1,0,0
0609 DEF S57B : 180,1,0,0
0610 DEF S57C : 180,1,0,0
0611
0612 '--- Servo 58: 180° (180°) ---
0613 DEF S58A : 180,1,0,0
0614 DEF S58B : 180,1,0,0
0615 DEF S58C : 180,1,0,0
0616
0617 '--- Servo 59: 180° (180°) ---
0618 DEF S59A : 180,1,0,0
0619 DEF S59B : 180,1,0,0
0620 DEF S59C : 180,1,0,0
0621
0622 '--- Servo 60: 180° (180°) ---
0623 DEF S60A : 180,1,0,0
0624 DEF S60B : 180,1,0,0
0625 DEF S60C : 180,1,0,0
0626
0627 '--- Servo 61: 180° (180°) ---
0628 DEF S61A : 180,1,0,0
0629 DEF S61B : 180,1,0,0
0630 DEF S61C : 180,1,0,0
0631
0632 '--- Servo 62: 180° (180°) ---
0633 DEF S62A : 180,1,0,0
0634 DEF S62B : 180,1,0,0
0635 DEF S62C : 180,1,0,0
0636
0637 '--- Servo 63: 180° (180°) ---
0638 DEF S63A : 180,1,0,0
0639 DEF S63B : 180,1,0,0
0640 DEF S63C : 180,1,0,0
0641
0642 '--- Servo 64: 180° (180°) ---
0643 DEF S64A : 180,1,0,0
0644 DEF S64B : 180,1,0,0
0645 DEF S64C : 180,1,0,0
0646
0647 '--- Servo 65: 180° (180°) ---
0648 DEF S65A : 180,1,0,0
0649 DEF S65B : 180,1,0,0
0650 DEF S65C : 180,1,0,0
0651
0652 '--- Servo 66: 180° (180°) ---
0653 DEF S66A : 180,1,0,0
0654 DEF S66B : 180,1,0,0
0655 DEF S66C : 180,1,0,0
0656
0657 '--- Servo 67: 180° (180°) ---
0658 DEF S67A : 180,1,0,0
0659 DEF S67B : 180,1,0,0
0660 DEF S67C : 180,1,0,0
0661
0662 '--- Servo 68: 180° (180°) ---
0663 DEF S68A : 180,1,0,0
0664 DEF S68B : 180,1,0,0
0665 DEF S68C : 180,1,0,0
0666
0667 '--- Servo 69: 180° (180°) ---
0668 DEF S69A : 180,1,0,0
0669 DEF S69B : 180,1,0,0
0670 DEF S69C : 180,1,0,0
0671
0672 '--- Servo 70: 180° (180°) ---
0673 DEF S70A : 180,1,0,0
0674 DEF S70B : 180,1,0,0
0675 DEF S70C : 180,1,0,0
0676
0677 '--- Servo 71: 180° (180°) ---
0678 DEF S71A : 180,1,0,0
0679 DEF S71B : 180,1,0,0
0680 DEF S71C : 180,1,0,0
0681
0682 '--- Servo 72: 180° (180°) ---
0683 DEF S72A : 180,1,0,0
0684 DEF S72B : 180,1,0,0
0685 DEF S72C : 180,1,0,0
0686
0687 '--- Servo 73: 180° (180°) ---
0688 DEF S73A : 180,1,0,0
0689 DEF S73B : 180,1,0,0
0690 DEF S73C : 180,1,0,0
0691
0692 '--- Servo 74: 180° (180°) ---
0693 DEF S74A : 180,1,0,0
0694 DEF S74B : 180,1,0,0
0695 DEF S74C : 180,1,0,0
0696
0697 '--- Servo 75: 180° (180°) ---
0698 DEF S75A : 180,1,0,0
0699 DEF S75B : 180,1,0,0
0700 DEF S75C : 180,1,0,0
0701
0702 '--- Servo 76: 180° (180°) ---
0703 DEF S76A : 180,1,0,0
0704 DEF S76B : 180,1,0,0
0705 DEF S76C : 180,1,0,0
0706
0707 '--- Servo 77: 180° (180°) ---
0708 DEF S77A : 180,1,0,0
0709 DEF S77B : 180,1,0,0
0710 DEF S77C : 180,1,0,0
0711
0712 '--- Servo 78: 180° (180°) ---
0713 DEF S78A : 180,1,0,0
0714 DEF S78B : 180,1,0,0
0715 DEF S78C : 180,1,0,0
0716
0717 '--- Servo 79: 180° (180°) ---
0718 DEF S79A : 180,1,0,0
0719 DEF S79B : 180,1,0,0
0720 DEF S79C : 180,1,0,0
0721
0722 '--- Servo 80: 180° (180°) ---
0723 DEF S80A : 180,1,0,0
0724 DEF S80B : 180,1,0,0
0725 DEF S80C : 180,1,0,0
0726
0727 '--- Servo 81: 180° (180°) ---
0728 DEF S81A : 180,1,0,0
0729 DEF S81B : 180,1,0,0
0730 DEF S81C : 180,1,0,0
0731
0732 '--- Servo 82: 180° (180°) ---
0733 DEF S82A : 180,1,0,0
0734 DEF S82B : 180,1,0,0
0735 DEF S82C : 180,1,0,0
0736
0737 '--- Servo 83: 180° (180°) ---
0738 DEF S83A : 180,1,0,0
0739 DEF S83B : 180,1,0,0
0740 DEF S83C : 180,1,0,0
0741
0742 '--- Servo 84: 180° (180°) ---
0743 DEF S84A : 180,1,0,0
0744 DEF S84B : 180,1,0,0
0745 DEF S84C : 180,1,0,0
0746
0747 '--- Servo 85: 180° (180°) ---
0748 DEF S85A : 180,1,0,0
0749 DEF S85B : 180,1,0,0
0750 DEF S85C : 180,1,0,0
0751
0752 '--- Servo 86: 180° (180°) ---
0753 DEF S86A : 180,1,0,0
0754 DEF S86B : 180,1,0,0
0755 DEF S86C : 180,1,0,0
0756
0757 '--- Servo 87: 180° (180°) ---
0758 DEF S87A : 180,1,0,0
0759 DEF S87B : 180,1,0,0
0760 DEF S87C : 180,1,0,0
0761
0762 '--- Servo 88: 180° (180°) ---
0763 DEF S88A : 180,1,0,0
0764 DEF S88B : 180,1,0,0
0765 DEF S88C : 180,1,0,0
0766
0767 '--- Servo 89: 180° (180°) ---
0768 DEF S89A : 180,1,0,0
0769 DEF S89B : 180,1,0,0
0770 DEF S89C : 180,1,0,0
0771
0772 '--- Servo 90: 180° (180°) ---
0773 DEF S90A : 180,1,0,0
0774 DEF S90B : 180,1,0,0
0775 DEF S90C : 180,1,0,0
0776
0777 '--- Servo 91: 180° (180°) ---
0778 DEF S91A : 180,1,0,0
0779 DEF S91B : 180,1,0,0
0780 DEF S91C : 180,1,0,0
0781
0782 '--- Servo 92: 180° (180°) ---
0783 DEF S92A : 180,1,0,0
0784 DEF S92B : 180,1,0,0
0785 DEF S92C : 180,1,0,0
0786
0787 '--- Servo 93: 180° (180°) ---
0788 DEF S93A : 180,1,0,0
0789 DEF S93B : 180,1,0,0
0790 DEF S93C : 180,1,0,0
0791
0792 '--- Servo 94: 180° (180°) ---
0793 DEF S94A : 180,1,0,0
0794 DEF S94B : 180,1,0,0
0795 DEF S94C : 180,1,0,0
0796
0797 '--- Servo 95: 180° (180°) ---
0798 DEF S95A : 180,1,0,0
0799 DEF S95B : 180,1,0,0
0800 DEF S95C : 180,1,0,0
0801
0802 '--- Servo 96: 180° (180°) ---
0803 DEF S96A : 180,1,0,0
0804 DEF S96B : 180,1,0,0
0805 DEF S96C : 180,1,0,0
0806
0807 '--- Servo 97: 180° (180°) ---
0808 DEF S97A : 180,1,0,0
0809 DEF S97B : 180,1,0,0
0810 DEF S97C : 180,1,0,0
0811
0812 '--- Servo 98: 180° (180°) ---
0813 DEF S98A : 180,1,0,0
0814 DEF S98B : 180,1,0,0
0815 DEF S98C : 180,1,0,0
0816
0817 '--- Servo 99: 180° (180°) ---
0818 DEF S99A : 180,1,0,0
0819 DEF S99B : 180,1,0,0
0820 DEF S99C : 180,1,0,0
0821
0822 '--- Servo 100: 180° (180°) ---
0823 DEF S100A : 180,1,0,0
0824 DEF S100B : 180,1,0,0
0825 DEF S100C : 180,1,0,0
0826
0827 '--- Servo 101: 180° (180°) ---
0828 DEF S101A : 180,1,0,0
0829 DEF S101B : 180,1,0,0
0830 DEF S101C : 180,1,0,0
0831
0832 '--- Servo 102: 180° (180°) ---
0833 DEF S102A : 180,1,0,0
0834 DEF S102B : 180,1,0,0
0835 DEF S102C : 180,1,0,0
0836
0837 '--- Servo 103: 180° (180°) ---
0838 DEF S103A : 180,1,0,0
0839 DEF S103B : 180,1,0,0
0840 DEF S103C : 180,1,0,0
0841
0842 '--- Servo 104: 180° (180°) ---
0843 DEF S104A : 180,1,0,0
0844 DEF S104B : 180,1,0,0
0845 DEF S104C : 180,1,0,0
0846
0847 '--- Servo 105: 180° (180°) ---
0848 DEF S105A : 180,1,0,0
0849 DEF S105B : 180,1,0,0
0850 DEF S105C : 180,1,0,0
0851
0852 '--- Servo 106: 180° (180°) ---
0853 DEF S106A : 180,1,0,0
0854 DEF S106B : 180,1,0,0
0855 DEF S106C : 180,1,0,0
0856
0857 '--- Servo 107: 180° (180°) ---
0858 DEF S107A : 180,1,0,0
0859 DEF S107B : 180,1,0,0
0860 DEF S107C : 180,1,0,0
0861
0862 '--- Servo 108: 180° (180°) ---
0863 DEF S108A : 180,1,0,0
0864 DEF S108B : 180,1,0,0
0865 DEF S108C : 180,1,0,0
0866
0867 '--- Servo 109: 180° (180°) ---
0868 DEF S109A : 180,1,0,0
0869 DEF S109B : 180,1,0,0
0870 DEF S109C : 180,1,0,0
0871
0872 '--- Servo 110: 180° (180°) ---
0873 DEF S110A : 180,1,0,0
0874 DEF S110B : 180,1,0,0
0875 DEF S110C : 180,1,0,0
0876
0877 '--- Servo 111: 180° (180°) ---
0878 DEF S111A : 180,1,0,0
0879 DEF S111B : 180,1,0,0
0880 DEF S111C : 180,1,0,0
0881
0882 '--- Servo 112: 180° (180°) ---
0883 DEF S112A : 180,1,0,0
0884 DEF S112B : 180,1,0,0
0885 DEF S112C : 180,1,0,0
0886
0887 '--- Servo 113: 180° (180°) ---
0888 DEF S113A : 180,1,0,0
0889 DEF S113B : 180,1,0,0
0890 DEF S113C : 180,1,0,0
0891
0892 '--- Servo 114: 180° (180°) ---
0893 DEF S114A : 180,1,0,0
0894 DEF S114B : 180,1,0,0
0895 DEF S114C : 180,1,0,0
0896
0897 '--- Servo 115: 180° (180°) ---
0898 DEF S115A : 180,1,0,0
0899 DEF S115B : 180,1,0,0
0900 DEF S115C : 180,1,0,0
0901
0902 '--- Servo 116: 180° (180°) ---
0903 DEF S116A : 180,1,0,0
0904 DEF S116B : 180,1,0,0
0905 DEF S116C : 180,1,0,0
0906
0907 '--- Servo 117: 180° (180°) ---
0908 DEF S117A : 180,1,0,0
0909 DEF S117B : 180,1,0,0
0910 DEF S117C : 180,1,0,0
0911
0912 '--- Servo 118: 180° (180°) ---
0913 DEF S118A : 180,1,0,0
0914 DEF S118B : 180,1,0,0
0915 DEF S118C : 180,1,0,0
0916
0917 '--- Servo 119: 180° (180°) ---
0918 DEF S119A : 180,1,0,0
0919 DEF S119B : 180,1,0,0
0920 DEF S119C : 180,1,0,0
0921
0922 '--- Servo 120: 180° (180°) ---
0923 DEF S120A : 180,1,0,0
0924 DEF S120B : 180,1,0,0
0925 DEF S120C : 180,1,0,0
0926
0927 '--- Servo 121: 180° (180°) ---
0928 DEF S121A : 180,1,0,0
0929 DEF S121B : 180,1,0,0
0930 DEF S121C : 180,1,0,0
0931
0932 '--- Servo 122: 180° (180°) ---
0933 DEF S122A : 180,1,0,0
0934 DEF S122B : 180,1,0,0
0935 DEF S122C : 180,1,0,0
0936
0937 '--- Servo 123: 180° (180°) ---
0938 DEF S123A : 180,1,0,0
0939 DEF S123B : 180,1,0,0
0940 DEF S123C : 180,1,0,0
0941
0942 '--- Servo 124: 180° (180°) ---
0943 DEF S124A : 180,1,0,0
0944 DEF S124B : 180,1,0,0
0945 DEF S124C : 180,1,0,0
0946
0947 '--- Servo 125: 180° (180°) ---
0948 DEF S125A : 180,1,0,0
0949 DEF S125B : 180,1,0,0
0950 DEF S125C : 180,1,0,0
0951
0952 '--- Servo 126: 180° (180°) ---
0953 DEF S126A : 180,1,0,0
0954 DEF S126B : 180,1,0,0
0955 DEF S126C : 180,1,0,0
0956
0957 '--- Servo 127: 180° (180°) ---
0958 DEF S127A : 180,1,0,0
0959 DEF S127B : 180,1,0,0
0960 DEF S127C : 180,1,0,0
0961
0962 '--- Servo 128: 180° (180°) ---
0963 DEF S128A : 180,1,0,0
0964 DEF S128B : 180,1,0,0
0965 DEF S128C : 180,1,0,0
0966
0967 '--- Servo 129: 180° (180°) ---
0968 DEF S129A : 180,1,0,0
0969 DEF S129B : 180,1,0,0
0970 DEF S129C : 180,1,0,0
0971
0972 '--- Servo 130: 180° (180°) ---
0973
```


3) MAIN1

MAIN1 sets the controls for the hand held remocon. If the RoboREMOCON program is not detected then the subroutine MAIN1 sets the controls for the robot. Within the routine is the command REMOCON that is discussed in more detail in the RoboBASIC Command Instruction Manual found on the CD.




4) Key Assignments and Motions

The remainder of the program relates to individual motions and the key assignments of the remocon.





B. Upload the Template Program

Start RoboBASIC and open the template program.




Connect the RoboNova-1 to the serial adapter and make sure it is turned on.



Click on "Run All" from the menu bar or the button in the tool bar.




"Run All" tool bar button



Once the program has been compiled, select ok on the Download window and the template program will upload into the controller.

Once the upload is complete, the robot will play music and move to the standard pose.





2. Adding Routines and Sensors

A. Create a Simple Routine

This section will show how easy it is to create new subroutines and add them to a remocon key.

Open the template program in RoboBASIC. Scroll to the last line in the program and create a new subroutine.


```
LED_toggle:
OUT 52,1
DELAY 1000
OUT 52,0
DELAY 1000
```



Add the new subroutine to Key 18 of the remocon. To do this, scroll to K18 in the template program and change it to:

```
K18:
GOSUB LED_toggle
GOTO main_exit
```

Connect the robot to the serial adapter and turn it on.



Either click the "RUN ALL" button on the tool bar or select it from the header "Compile" in the menu bar.



Run All tool bar button

After the program has been uploaded to the controller, pressing the "E" button (Key 18) of the remocon will cause the LED in the head to blink twice.

B. Adding a Gyro

Up to four gyros can be used at one time in the RoboNova-1 to increase stability. The gyros are plugged into two separate AD ports, one for input, and one for output. The RoboBASIC commands for the gyros are, GYRODIR (which direction the servos will turn), GYROSET (which servos respond to the specific gyro), and GYROSENSE (servo sensitivity to the gyro). The specifics of these commands will not be covered here but can be found in the RoboBASIC Command Instruction Manual found on the CD.

Most single rate piezo gyros with gain adjustment can be used with the RoboNova-1.



Connection to the controller involves two AD ports. As an example, gyro #1 is connected to AD(0) and AD(4) ports of the controller. Connect the input from the controller to the gyro in AD(0) and the output from the gyro to controller in AD(4).

There are four gyro ports.

Gyro port #1: AD(0), AD(4)

Gyro port #2: AD(1), AD(5)

Gyro port #3: AD(2), AD(6)

Gyro port #4: AD(3), AD(7)

Here is an example of the code for a gyro:

```
GYROSET G6A, 0,1,1,1,0,0
GYROSET G6D, 0,1,1,1,0,0
```

'servos 2, 3, and 4 in motor group A are controlled by Gyro #1
'servos 2,3, and 4 in motor group D are controlled by Gyro #1

```
GYRODIR G6A, 0,0,0,0,0,0
GYRODIR G6D, 0,0,0,0,0,0
```

'servos in motor group A will turn in their normal directions
'servos in motor group D will turn in their normal directions

```
GYROSENSE G6A, 0,250,250,250,0,0,0
GYROSENSE G6D, 0,250,250,250,0,0,0
```

'servos 2, 3, and 4 in motor group A are set to their highest sensitivity
'servos 2, 3, and 4 in motor group D are set to their highest sensitivity

C. I2C

The MR-C3024 controller board has the ability to communicate via the I2C serial protocol with the SDA and SDL pins.

The following is an example of the code.

```
CONST SCL = 22
CONST SDA = 23
```

```
DIM A AS BYTE
DIM I AS BYTE
DIM CODE AS BYTE
```

```
'=====
I2C_SAMPLE:
'=====
A = IN(SDA)
S1: OUT SCL,0
   OUT SCL,1
'=====
S3: OUT SDA,0
   OUT SCL,0
   OUT SCL,1
'=====
OUT SDA, 1
OUT SCL, 0
OUT SCL, 1
```

```
OUT SDA, 0
OUT SCL, 0
OUT SCL, 1
```

```
OUT SDA, 0
OUT SCL, 0
OUT SCL, 1
```

```
OUT SDA, 1
OUT SCL, 0
OUT SCL, 1
```

```
'=====
CODE = 0
FOR I = 0 TO 7
  OUT SCL, 0
  OUT SCL, 1
  A = IN(SDA)
  A = A<<1
  CODE = CODE OR A
NEXT I
'=====
RETURN
```

VIII. HMI Protocol

The HMI Protocol (Hitec Multi-protocol Interface) is a newly created interface for the HITEC programmable robot servos. (For more detailed programming of the servos, an optional settings kit is required.)


*The following information can be of use to high-end users as it concerns the pulse data. This pulse data is required for location (angle) feedback between HITEC robotic servos and a PC.

The servos will execute a specified movement when four kinds of pulses are inputted from an outside source.


- ☐ 1) 50usec pulse width / Location (angle) value feedback
- ☐ 2) 100usec pulse width / Use servo parameter 1 value (default)
- ☐ 3) 150usec pulse width / Use servo parameter 2 value
- ☐ 4) 200usec pulse width / Use servo parameter 3 value

Note: To use the location (angle) feedback with an external circuit, the control signal terminal must have bidirectional functions. To read the feedback value, a pull-up process must be performed in the signal line.


Control signal 50μsec



Control signal 100μsec



Control signal 150μsec



Control signal 200μsec



Note: Since this function is used in conjunction with the PWM control, there is a 10% error rate.

IX. Troubleshooting

1. Unable to connect to RoboBASIC:

If when connecting the robot via the serial cable to RoboBASIC and an error code 0 or 4 appears, check these items.

1. The robot is turned on and the serial cable is connected to it and the serial port of the PC.
2. That roboBASIC is set to the correct COM port. To do this, open the Windows Device Manager and locate the COM port settings.
3. Make sure that the battery is fully charged.
4. If an after markets USB to serial interface is being used, check with the manufacturer for proper installation.

If these steps do not solve the problem, contact Hitec Robotics for assistance.

2. Servos are not moving in the right direction.

If one or more servos are moving in the wrong direction, double check the splined horn alignment and that the correct servo is installed in the corresponding joint. The servo placement chart will assist in this.

3. Servo is overheating.

If excess heat is felt from one servo, turn the robot off immediately.

Check the splined horn alignment. If it is incorrect, adjust it so it matches the correct position according to the assembly instructions. Also check that the joint is moving freely and not straining against a bracket or wiring.

If the problem persists, contact Hitec Robotics for assistance.

4. Head LED is constantly blinking.

Reload the overall_template_program.bas with the line GOSUB robot_voltage remarked out.

In order to use this subroutine, a special circuit must be installed in the robot. A previous section shows the circuit and installation.

5. The remocon does not communicate with the robot.

The remocon and the RoboNova have the ability to be programmed with four different IDs. Make sure the ID of the remocon matches the one programmed into the RoboNova. If the robot is being used under bright lights, the lighting will interfere with the IR receiver.

6. How do I connect a sensor.

There are many after market sensors available online. The RoboBASIC command manual should be the first place to look when installing and using different sensors.


Another valuable resource is the online community. The Hitec Robotics forum is a place where individuals can post their questions and share their knowledge. As well as our forum, many private forums deal with the RoboNova-1.

HMI (Hitec Multi-protocol Interface) provides you with an interface to program the HITEC Robot Servos. This information is only available for HITEC Robot Servos with firmware versions 1.10 or above. (To program all the features of the Robot Servos, an optional kit is required.)


1. HMI Protocol Pulse

In this section, the structure of the HMI Protocol Pulse is described for advanced users wishing to know the exact positions of HITEC Robot Servos connected to a PC. Users can get the Feedback Data from servos using a Micom that is programmed to output 4 types of pulses to the servo and to receive a feedback pulses from the servo through the signal wire of the servos.


1) 50 μ s Pulse Width / Position Value Feedback



2) 100 μ s Pulse Width / Use Parameter #1 value of servo (default)



3) 150 μ s Pulse Width / Use Parameter #2 value of servo.



4) 200 μ s Pulse Width / Use Parameter #3 value of servo



- Parameter #1: Default
- Parameter #2 and #3: Reserved Parameter. It is possible to setup parameter #2 and #3 with the HMI Servo Programmer Kit (optional item). To set the servos operating characteristics during operation, a user will have to create a custom program using the open source code found at <http://www.hitecrobotics.com>.

Note1: To get position feedback using an external circuit, the communication port of the controller must be bi-directional, and the signal terminal should be setup in a Pull-Up state.

Note2: Because the positional feedback mentioned in note 1 operates in conjunction with the PWM control function, there is a chance that a communication error will occur 10% of the time.

2. Parameters that can be set using the HMI Servo Programmer kit

- D-gain Parameter
- Dead Zone Parameter
- P-gain Parameter

3. PC to Servo Serial Interface

- Through the serial port of a PC, HMI can control up to 127 HITEC Robot Servos (which are programmable with HMI) directly without any interconnection devices.

- The number of servos that can be controlled through the serial port is dependent on the PC environment and interface (especially on the signal level of the serial port).

- In the case of Voltage/Current Feedback, the value is presented as an integer (0~256), so users will have to convert the integer to make sense of it as a physical value.

1) B_Version : Verifying ID and Version <- Feedback the ID and Version of the Servo

B_Version	80	E7	0	0	version	ID
-----------	----	----	---	---	---------	----

>> Packet Command

HEADER	Command	Data1	Data2	CHKSUM	Receive[0x00]	Receive[0x00]
1byte	1byte	1byte	1byte	1byte	1byte	1byte

- header = 0x80 (packet start)
- command = 0xE7
- data1 = 0x00
- data2 = 0x00
- check = header + command + data1 + data2
- NULL = 0x00
- NULL = 0x00

>> Packet Receive

Recieve[Data1]	Receive[Data2]
1byte	1byte

- data1 = version <-version feedback
- data2 = ID <-ID feedback

B_Version	80	E8	0	0	current	voltage
-----------	----	----	---	---	---------	---------

2) B_Battery : Verifying Voltage and Current.

>> Packet Command

HEADER	Command	Data1	Data2	CHKSUM	Receive[0x00]	Receive[0x00]
1byte	1byte	1byte	1byte	1byte	1byte	1byte

- header = 0x80(packet start)
- command = 0xE8
- data1 = 0x00
- data2 = 0x00
- check = header + command + data1 + data2
- NULL = 0x00
- NULL = 0x00

>> Packet Receive

Recieve[Data1]	Receive[Data2]
1byte	1byte

- data1 = current <-Current feedback
- data2 = voltage <-Voltage feedback

3) B_ID_R_POS_PC : Setting up motor speed and verifying position

B_ID_R_POS_PC	80	E9	00-7F(ID)	speed	pos_H	pos_L	ID
---------------	----	----	-----------	-------	-------	-------	----

>>Packet Command

HEADER	Command	Data1	Data2	CHKSUM	Receive[0x00]	Receive[0x00]
1byte	1byte	1byte	1byte	1byte	1byte	1byte

- header = 0x80 (Packet Start)
- command = 0xE9
- data1 = 00-7F(ID)
- data2 = speed <- Setting up speed
- check = header + command + data1 + data2
- NULL = 0x00
- NULL = 0x00

>> Packet Receive

Recieve[Data1]	Receive[Data2]
1byte	1byte

- data1 = pos_H <- High byte of position feedback value
- data2 = pos_L <- Low byte of position feedback value

4) B_ID_W_MOV_MAX : Setting up motor position

B_ID_W_MOV_MAX	80	E9	00-7F(ID)	pos_H	pos_L	-	-	ID
----------------	----	----	-----------	-------	-------	---	---	----

>> Packet Command

HEADER	Command	Data1	Data2	CHKSUM	Receive[0x00]	Receive[0x00]
1byte	1byte	1byte	1byte	1byte	1byte	1byte

- header = 0x80(Packet Start)
- command = 00-7F(ID)
- data1 = pos_H <- Writing high byte of position command
- data2 = pos_L <- Writing low byte of position command
- check = header + command + data1 + data2
- NULL = 0x00
- NULL = 0x00

>> Packet Receive

Recieve[Data1]	Receive[Data2]
1byte	1byte

- data1 = 0x00 <- High byte of current position value feedback
- data2 = 0x00 <- Low byte of current position value feedback

5) B_motor_go_stop : Motor operation setup

B_motor_go_stop	80	EB	0	0/1	03	03	0:stop 1:go
-----------------	----	----	---	-----	----	----	-------------

>> Packet Command

HEADER	Command	Data1	Data2	CHKSUM	Receive[0x00]	Receive[0x00]
1byte	1byte	1byte	1byte	1byte	1byte	1byte

- header = 0x80(Packet Start)
- command = EB
- data1 = 0
- data2 = 0x00 / 0x01 (0- stop / 1- go)
- check = header + command + data1 + data2
- NULL = 0x00
- NULL = 0x00

>> Packet Receive

Recieve[Data1]	Receive[Data2]
1byte	1byte

- data1 = 0x03
- data2 = 0x03

You can find more detailed information at the HITEC Robotics Home Page (<http://www.hitecrobotics.com>) and download all articles of interest.

4. Overload Protection

The HITEC Robot Servos have an Overload Protection Function, which is intended to protect motor, amplifier, and Robot.

- If overload occurs, the overload protection is activated and the power to the servo is turned off within 10 seconds.
- Overload protection is removed when the power is cycled to the servo.
- For safety, the overload protection function is not user-programmable.

5. After the power to the servo has cycled, it will move slowly to neutral. Thereafter, it will operate normally. This is not a malfunction.

6. Robot Servos usually have high torque, so users need to be very careful handling the robot while it is operating. Carelessly touching a joint or servo may cause injury.

7. HITEC Robot Servos are developed for Robot Control only. Use of them for the other applications (RC, etc) is prohibited.